




Selection and ordering data



For contactors	Rated operational current <sup>2)</sup> NEMA A600 / Q600	Auxiliary contacts		Screw connection		Cage Clamp connection		Weight approx. kg
		Ident. no.	Design	Order No.	List Price \$	Order No.	List Price \$	
Type			 NO NC NO NC					

Auxiliary switch blocks for snapping onto the front acc. to EN 50 012 <sup>1)</sup>

Size S00

For making contactors with 2, 4 or 5 auxiliary contacts

3RT10 1.-1...1, 3RT10 1.-2...1 Ident. no. 10E	<b>11 E</b>	-	1	-	-	<b>3RH19 11-1HA01</b>	<b>3RH19 11-2HA01</b>	0.045
	<b>22 E</b>	1	2	-	-	<b>3RH19 11-1HA12</b>	<b>3RH19 11-2HA12</b>	
	<b>23 E</b>	1	3	-	-	<b>3RH19 11-1HA13</b>	<b>3RH19 11-2HA13</b>	
	<b>32 E</b>	2	2	-	-	<b>3RH19 11-1HA22</b>	<b>3RH19 11-2HA22</b>	

Sizes S0 to S12 <sup>1)</sup>

4-pole

3RT10 2, 3RT1. 3 to 3RT1. 7, 3RT11	<b>31</b>	3	1	-	-	<b>3RH19 21-1HA31</b>	<b>3RH19 21-2HA31</b>	0.065
	<b>22</b>	2	2	-	-	<b>3RH19 21-1HA22</b>	<b>3RH19 21-2HA22</b>	
	<b>13</b>	1	3	-	-	<b>3RH19 21-1HA13</b>	<b>3RH19 21-2HA13</b>	
with location digits 5, 6, 7, 8	<b>22</b>	2	2	-	-	<b>3RH19 21-1XA22-0MA0</b>	<b>3RH19 21-2XA22-0MA0</b>	

Auxiliary switch blocks for snapping onto the front acc. to EN 50 005 <sup>1)</sup>

Size S00

2 or 4-pole auxiliary switch blocks for making contactors with 3 or 5 auxiliary contacts

3RT1. 1, 3RH11, 3RH14	<b>20</b>	2	-	-	-	<b>3RH19 11-1FA20</b>	<b>3RH19 11-2FA20</b>	0.045
	<b>11</b>	1	1	-	-	<b>3RH19 11-1FA11</b>	<b>3RH19 11-2FA11</b>	
	<b>02</b>	-	2	-	-	<b>3RH19 11-1FA02</b>	<b>3RH19 11-2FA02</b>	
	<b>11 U</b>	-	-	1	1	<b>3RH19 11-1FB11</b>	<b>3RH19 11-2FB11</b>	
	<b>40</b>	4	-	-	-	<b>3RH19 11-1FA40</b>	<b>3RH19 11-2FA40</b>	0.045
	<b>31</b>	3	1	-	-	<b>3RH19 11-1FA31</b>	<b>3RH19 11-2FA31</b>	
	<b>22</b>	2	2	-	-	<b>3RH19 11-1FA22</b>	<b>3RH19 11-2FA22</b>	
	<b>22 U</b>	-	-	2	2	<b>3RH19 11-1FC22</b>	<b>3RH19 11-2FC22</b>	
	<b>11, 11 U</b>	1	1	1	1	<b>3RH19 11-1FB22</b>	-	

Single or 2-pole auxiliary switch blocks, cable entry from one side

• Cable entry from above	-	1	-	-	-	<b>3RH19 11-1AA10</b>	-	0.015
	-	-	1	-	-	<b>3RH19 11-1AA01</b>	-	
	-	1	1	-	-	<b>3RH19 11-1LA11</b>	-	0.045
	-	2	-	-	-	<b>3RH19 11-1LA20</b>	-	

• Cable entry from below

-	1	-	-	-	-	<b>3RH19 11-1BA10</b>	-	0.015
-	-	1	-	-	-	<b>3RH19 11-1BA01</b>	-	
-	1	1	-	-	-	<b>3RH19 11-1MA11</b>	-	0.045
-	2	-	-	-	-	<b>3RH19 11-1MA20</b>	-	

EN50005 and EN50012 designate the markings of the auxiliary terminal numbers. For position of the terminals see pages 2/166-169. For int. circuit diagrams see pages 2/156-160

- 1) Exception: 3RT16.
- 2) UL ratings, Appendix page 19/7.